SAMSUNG Office DECT 8000

> Installation and Programming Manual





Publication Information

Samsung Telecoms reserves the right without prior notice to revise information in this publication for any reason.

Samsung Telecoms also reserves the right without prior notice to make changes in design or components of equipment as engineering and manufacturing may warrant.

Disclaimer

Samsung Telecoms is not responsible for errors or problems arising from customers not installing, programming or operating their Samsung systems as described in this manual.

Copyright 2001 Samsung Telecoms (U.K.) Limited

All rights reserved. No part of this manual may be reproduced in any form or by any means - graphic, electronic or mechanical, including recording, taping, photocopy or information retrieval system - without express written permission of the publisher of this material.



EU Declaration of Conformity (R&TTE)

Tae Kwang Industrial Co., Ltd

191-1, Anyang-7dong, Manan-gu, Anyang City, Gyunggi-do, Korea (factory name, address)

declare under our sole responsibility that the product

Digital Keyphone DECT "Office DECT 8000"

To which this declaration relates is in conformity with

R&TTE Directive 1999/5/EC (Annex III) Low Voltage Directive 73/23/EEC EMC Directive 89/336/EEC:92/31/EEC

By application of the following standards

CTR6 (July 1997) EN 301 489-1-6 : 2000 EN 50081-1 : 1993 EN 50082-1 : 1997 EN 60950 : 1997

(Manufacturer) ACRO Telecom Co., Ltd 5F Hwachon Bldg, 334-1 Yangjaedong Seochogu, Seoul, Korea

2001 03 20 K H Kim

(place and date of issue)

(Representative in the EU) Samsung Telecoms (UK) Ltd Unit B2, Brookside Business Park, Greengate, Middleton, Manchester M24 1GS, United Kingdom

2001 05 28 D Norton

(place and date of issue)

CE 0681



Kyoung-Hyun Kim / President (name and signature of authorized person)

David Norton / Managing Director (name and signature of authorized person)

For other declarations relevant to DCS and DCS Compact II systems, refer to the Samsung Telecoms website at: www.samsung-telecoms.co.uk

Intended Use

This DECT telephone handset is intended to communicate with a Samsung telephone system, where such a telephone system is provided with the appropriate DECT interface. It allows the user to make and receive voice calls. An optional ear-microphone (headset) unit can be connected. The telephone is powered by an integral battery which is charged through the base unit provided. It should not be used for any other purpose.

Contents

Chapter 1 DECT System Overview	1-1~1-5
What is DECT?	
History	1-2
What Standards Define DECT ?	
Specifications for DECT	1-2
DECT Time Slot and Frame Structure	1-3
Basic Functions of the DECT System	1-3
List of Abbreviations	1-5
Chapter 2 DECT System Components	2-1~2-4
Base Station Interface (BSI) Card	2-1
3BSI Card	2-1
4BSI Card	2-2
8BSI Card	2-3
DECT Base Station (DBS)	2-4
Chapter 3 Site Survey with Office DECT 8000	3-1~3-10
Considerations	
Before Starting the Site Survey	3-3
Site Survey Procedure	
Checklist for Survey Data	3-5
Reporting Site Survey Results	
Example Cell Planning Results	
Chapter 4 Installation	4-1~4-18
Installation Procedure	4-1
Installing BSI Card	4-2
Installing 3BSI Card in COMPACT II	
Installing 4BSI and 8BSI Card in DCS	4-3
Connecting BSI Card and DBS	4-6
Cable Requirements	4-6
Connecting Cable to Compact II	4-11
Connecting Cable to DCS	4-12
Connecting Cable to DBS	4-12
Installing DBS	4-14
Tools Required	4-14
Fixing the Wall-Mount Bracket	
Fixing a DBS on the Wall-Mount Bracket	
Setting DECI System Parameters	
Unice DECT 8000 Registration	4-18

Chapter 5 MMC Programming	5-1~5-11
MMC 202 : CHANGE FEATURE PASSCODES	5-1
MMC 724 : DIAL NUMBER PLAN	5-2
MMC 737 : DECT SYSTEM CODE	5-3
MMC 738 : CLEAR REGISTRATION	5-4
MMC 739 : BSI DOWNLOAD	5-5
MMC 740 : STATION PAIR	5-6
MMC 741 : DBS RESTART	5-7
MMC 742 : BSI STATUS	5-8
MMC 743 : DBS STATUS	
MMC 744 : DECT REGISTRATION ON/OFF	5-10
MMC 745 : BSI CARRIER	5-11
Chapter 6 Maintenance	6-1~6-16
Chapter 6 Maintenance	6-1~6-16 6-1
Chapter 6 Maintenance	6-1~6-16 6-1 6-1
Chapter 6 Maintenance	6-1~6-16
Chapter 6 Maintenance Upgrading Software fOR BSI Card and DBS Upgrading Software for BSI Card Upgrading DBS Software Tools Required for Maintenance	6-1~6-16 6-1 6-1 6-1 6-7 6-8
Chapter 6 Maintenance Upgrading Software fOR BSI Card and DBS Upgrading Software for BSI Card Upgrading DBS Software Tools Required for Maintenance LED Descriptions	 6-1~6-16
Chapter 6 Maintenance Upgrading Software fOR BSI Card and DBS Upgrading Software for BSI Card Upgrading DBS Software Tools Required for Maintenance LED Descriptions LEDs on the DBS	6-1~6-16 6-1 6-1 6-1 6-7 6-8 6-8 6-8 6-8 6-8
Chapter 6 Maintenance Upgrading Software fOR BSI Card and DBS Upgrading Software for BSI Card Upgrading DBS Software Tools Required for Maintenance LED Descriptions LEDs on the DBS Troubleshooting	6-1~6-16 6-1 6-1 6-1 6-7 6-8 6-8 6-8 6-8 6-8 6-9
Chapter 6 Maintenance Upgrading Software fOR BSI Card and DBS Upgrading Software for BSI Card Upgrading DBS Software Tools Required for Maintenance LED Descriptions LEDs on the DBS Troubleshooting	6-1~6-16 6-1 6-1 6-1 6-7 6-8 6-8 6-8 6-8 6-8 6-9

Appendix B Office DECT 8000 Handset Test Mode Description	. B-1~B-2
Running Test Mode	B-1
Handset Factory Reset	B-2

Chapter 1 DECT System Overview

This overview provides instructions for using a Digital European Cordless Telecommunications (DECT) system with the Samsung DCS or DCS Compact II keyphone system. In this manual, the DCS system is referred to as "DCS" and the DCS Compact II system is referred to as "Compact II." Various DECT handsets from many different manufacturers are compatible with DECT systems.

DECT systems offer a complete range of keyphone systems and handsets that can be used to provide DECT cordless communications in a single office or throughout a large commercial or industrial complex. This improves overall efficiency, since staff can be reached or can make calls wherever they are. These systems also provide existing keyphone functions that are commonly used in business environments. The use of cordless extensions reduces the cost and inconvenience associated with reconfiguring wired extensions as people move offices, or as the company is reorganised.

The DECT system comprises a DCS or Compact II keyphone system, a base station interface (BSI) card, and one or more DECT base stations (DBSs). The BSI card provides the interface between the keyphone system and the DBSs and is installed in the keyphone system. In the example below, the DECT system is a DCS keyphone system fitted with an 8BSI card interfacing with up to eight DBSs.



Example DECT System

What is DECT?

History

DECT was born in 1988 when the European Conference of Postal and Telecommunications Administrations (known as CEPT) decided to standardise on a Pan-European cordless communication format which would operate just below 2GHz. Later in 1988 the ownership of the DECT standard was handed over to the European Telecommunications Standards Institute (ETSI) which has been responsible for the development of the standard since then.

What Standards Define DECT?

ETSI regulations that define DECT are CTR-06, CTR-10, and CTR-22.

CTR-06

CTR-06 is the standard which defines all the Radio Frequency (RF) tests which need to be carried out on the DECT physical layer. CTR-06 specifies all transmitter and receiver tests, detailing test conditions, techniques and specifications.

CTR-10

CTR-10 is the standard which specifies the audio test requirements for DECT, making sure that DECT equipment meets all of the required performance criteria for audio quality, distortion, etc.

CTR-22

CTR-22 defines the Generic Access Profile, the ability of a manufacturer's equipment to operate with every other manufacturer's.

Specifications for DECT

DECT is a standard for cordless telecommunication among European countries adopting the DECT as a standard for their own cordless telecommunication. DECT uses pico-cellular technology and can handle high-density traffic. Specifications for DECT are as follows:

• Frequency:	1880-1900MHz (20MHz bandwidth)
• RF channel bandwidth:	1.728MHz
• Number of carriers:	10
Channel spacing:	2 MHz
• Multiple access scheme:	TDMA/FDMA/TDD
• Number of time slots in one:	24
• Number of duplex channels per frame:	12
• GFSK (Gaussian Frequency Shift	
Keying) Modulation	
G721 ADPCM 32kHz voice coding	
Data transmission rate per one slot is	
1.152Mbps	
DECT identifier and registration:	The identifier is used for authentication of DECT handsets at registration, declaration of hand-
	set location to the DBS, and handover.

DECT Time Slot and Frame Structure



Basic Functions of the DECT System

DECT System

- The DECT system uses a pico-cellular technology (the cell range is 15 m to 300 m depending on the environment).
- The frequency ranges between 1,880 and 1,900MHz (UHF); i.e. 20MHz is shared out into 10 carriers.
- The pass-range of a channel is equal to 1.728MHz and two channels are separated by 2MHz in order not to disturb the neighbouring channels.

DCS System

The DCS system:

- controls and maintains the BSI;
- maintains and downloads DBS functions;
- controls the data from the DECT handset, and sends display data to the DECT handset.

DBS

- A DBS uses one of 10 channels (FDMA technology) and 24 time slots per frequency (TDMA technology).
- GFSK (Gaussian Frequency Shift Keying) modulation technology is used.

BSI

The BSI:

- maintains subscriber information and communicates with the DCS system;
- handles fault information.

Handover

This is a function/procedure that handles the physical channel changes between slots or cells. To make a seamless handover between a DBS and a handset, a new channel needs to be set up and a connection made using the new channel. At this point, both new and old channels are used simultaneously. After establishing the new connection, the old connection is broken.

Handover request is initiated by the DECT handset. Therefore, adequate cell-site design for the DECT handsets being used is essential for seamless handover.

Roaming

When a DECT user moves around, the DECT handset searches for a DBS with the strongest signal and registers its location with that DBS even though it may not be making or receiving any calls. Due to this registration, the precise location of each of the handsets is known at all times. Therefore, all incoming/outgoing calls are processed without any loss of connection within the RF coverage area. If the user has a valid registration with other systems, inter-system roaming can be made available.

Voice Quality

The 32kbps ADPCM voice coding standard is used in DECT. The digitally coded voice is transmitted between the DBS and the DECT handset. DECT uses a muting method to remove the noise caused by lost data and RF propagation conditions. The DECT handset continuously looks for the best time slot and frequencies from the available time slots and frequencies. This is called Dynamic Channel Selection (DCS). Digital Signal Processing (DSP) on the DBS performs echo-cancellation/suppression to reduce the echo caused by the analogue trunk line and PSTN network. In addition, the DBS has two antennas and the stronger signal is selected for communication. In addition, the antenna on which the DBS received the stronger signal is used for the forward link.

Synchronisation

Under multi-cell configuration, all DBSs must maintain the same RF transmit timing for handover because DECT is working under Time Division Multiple Access (TDMA). The system can distribute the timing information to all DBSs for multi-frame data signalling. DCS does not support an external synchronisation port.

Other Functions

- Registration/De-registration of DECT handset.
- Making a call to/from DECT handset.
- Location registration.
- Handover / Internal handover (Inter-cell /Intra-cell handover), Connection/Bearer handover.
- Management of DBS and handset.
- Additional features (supports DECT Frame SYNC/ Multi-Frame SYNC, etc.)

List of Abbreviations

ADPCM	Adaptive Differential Pulse Code Modulation	PMID
AF	Audio Frequency	PP
BER	Bit Error Rate	RF
BL	Baseset Logic	RFP
BMC	Burst Mode Controller	RSSI
BPF	Band Pass Filter	SAP
BRF	Baseset Radio Frequency	TCM
BSI	Base Station Interface (card)	TDD
CEPT	European Conference of Postal and	TDMA
	Telecommunications Administrations	VCO
DBS	DECT Base Station	
DCS (1)	Digital Communications System (Samsung)	
DCS (2)	Dynamic Channel Selection	
DECT	Digital European Cordless Telecommunications	
DSP	Digital Signal Processing	
DTMF	Dual Tone Multi Frequency	
ESD	Electrostatic Sensitive Devices	
ETSI	European Telecommunications Standards Insti- tute	
FDMA	Frequency Division Multiple Access	
FMID	Fixed Part MAC Identity	
FP	Fixed Part	
GAP	Generic Access Profile	
GFSK	Gaussian Frequency Shift Keying	
HL	Handset Logic	
HRF	Handset Radio Frequency	
I/F	Interface	
IIC	Inter-Integrated Circuit	
LCD	Liquid Crystal Display	
LNA	Low Noise Amplifier	
LPF	Low Pass Filter	
MMC	Man Machine Code	
MOH	Music On Hold	
NTP	Normal Transmitted Power	
PARI	Primary Access Rights	
PCB	Printed Circuit Board	
PCM	Pulse Code Modulation	
PIN diode	Positive Intrinsic Negative diode	

Portable Part MAC Identity
Portable Part (a DECT handset)
Radio Frequency
Radio Fixed Part (a DBS)
Receive Signal Strength Indicator
Service Access Rights
Time Compression Multiplexed
Time Division Duplex
Time Division Multiple Access
Voltage Controlled Oscillator

Chapter 2 DECT System Components

Base Station Interface (BSI) Card

The BSI card is designed to support communication between the DCS system and DECT base stations (DBS). There are three types of BSI card: 3BSI, 4BSI, and 8BSI.

Characteristics	3BSI	4BSI	8BSI
System type	Compact II	DCS	DCS
Maximum number of DBSs connected	3	4	8
Maximum number of handsets registered	24	32	48
Maximum number of calls established simultaneously	12	16	32
Maximum number of cards installed in system	1	1	1

Important information

1 There is a priority among PRI, BRI, and some BSI cards in cases where multiple types of cards are installed in a system. PRI has the highest priority level, BRI has the next level and BSI the lowest level (PRI > BRI > BSI).

When using a combination of these cards, higher priority cards must be allocated to lower numbered slots in the system.

2 You cannot install both a 4BSI card and an 8BSI card in the same DCS system.

3 If installing an 8BSI card, remember that it uses two slots, so you cannot insert another card in the adjacent slot.

3BSI Card

.....

The 3BSI card can only be installed in a Compact II system. The card can connect with up to three DBSs. Each DBS can have four simultaneous calls and, therefore, 12 simultaneous calls can be established via one 3BSI card. You can register up to 24 DECT handsets to a single 3BSI card.

The card is illustrated below and is installed as described in Chapter 4, Installation.

3BSI Card



4BSI Card

The 4BSI card can only be installed in a DCS system. The 4BSI card can connect up to four DBSs. Each DBS can have four simultaneous calls and, therefore, 16 simultaneous calls can be established via one 4BSI card. You can register up to 32 DECT handsets to a single 4BSI card.

The card is illustrated below and is installed as described in Chapter 4, Installation.



Champ Connector

The champ connector is used for connecting with DBSs.

8BSI Card

The 8BSI card can only be installed in a DCS system. The 8BSI card has more features and more enhanced performance than the 4BSI card.

- Each 8BSI card can connect up to eight DBSs and have 32 simultaneous calls (four per DBS).
- 48 DECT handsets can be registered to a single card.
- You can easily download new software from a console terminal connected to the RS-232C connector on the front panel of the card.
- Power feeding of each port can be controlled remotely using the software.
- The Watchdog timer prevents the system from operating abnormally due to voltage change.
- The system monitoring feature is enhanced by using a manual reset switch and a non-maskable interrupt reset switch.

The card is illustrated below and is installed as described in Chapter 4, Installation.



Champ Connector

The champ connector is used for connecting with DBSs.

RS-232C Connector

This 9-pin connector is used for connecting a console terminal to download the 8BSI card software (see Chapter 6).

DECT Base Station (DBS)

The DBS is installed as a wireless base station for the DECT integrated wireless system. The DBS performs the lower MAC of the DECT protocol through a radio link. Handset communication is enabled by interfacing TCM (Time Compression Multiplexed) with the keyphone system.

The DBS is installed as shown in Chapter 4, Installation.

Front View



Rear View



Chapter 3 Site Survey with Office DECT 8000

A site survey is required to define the number and the location of DECT base stations (DBSs) needed to cover the area of a site adequately.

Considerations

Due to the nature of radio waves, wireless telecommunication, to a large extent, depends on the environmental characteristics of a site.

- The signal strength of radio waves transmitted from a DBS should be measured at several points carefully. The results can then be recorded in the form of contour lines on the site map.
- A great deal of time and effort can be saved if simulation devices or measuring devices are available.
- If no measuring devices are available, the DBS and an Office DECT 8000 handset can be used to measure the strength of radio signals.
- All the test results should be kept safely for effective maintenance of the site.

Environmental Considerations for Users and Buildings

- Carefully track the movement of users to establish movement patterns.
- The number of DBSs required is determined by the number of users.
- The distance between DBSs should be at least 3m to avoid interference. Keep the distance between DBSs shorter the more frequently users move while in conversation.
- Do not install a DBS where it could spoil architectural features.
- Consider ease of maintenance when installing a DBS.

Other Considerations

• There should be at least one DBS with an RSSI (Receive Signal Strength Indicator) value greater than A0 (hex) at some location within the service area for DECT users. Refer to Table 1.

RSSI Value (Hex)	Voice Quality
C0 ~ FF	Good
A0 ~ BF	Satisfactory
90 ~ 9F	Poor
~7A	Call disconnection

Table 1: RSSI Values

• Take into account radio interference caused by objects such as trees, walls and glass. Try to install in an open environment where masking by objects is minimised. Refer to Table 2 for details.

Material	Approximate Loss in dB		
Glass	2		
Glass, metal reinforced grid	10		
Glass, metal-clad sunguard	10		
Wall, indoor, wood	2		
Wall, brick, 10cm	3.5		
Wall concrete, 15cm	9		
Wall concrete, 20cm, large win- dows	6		
Wall concrete, 40cm	17		
Concrete	15		
Concrete, metal clad	30		
Concrete, window	8-9		
Venetian blinds open	10		
Venetian blinds closed	20		
Soft partitioning	3-4		

Table 2: Radio Interference by Materials

- When installing cables for DBSs, keep them away from high-speed LAN cables and power cables which can cause electrical interference. Maintain at least 1m distance.
- Avoid installing a DBS near windows since radio interference between floors of a building might be more active due to diffraction of radio waves.
- It is recommended that a DBS should be installed at a distance of 2m from the floor and 30cm from the ceiling, and cables should come from the ceiling rather than the floor.
- The distance between each DBS should be at least 3m.
- Take into account interference from adjacent cells when the DECT system is installed in a multi-storey building.
- For overlapped and multi-cell systems, the distance between DBSs should ideally be about 30

 50m for indoor use, and about 300m for open outdoor areas. However, these values are rarely achieved in practice due to the variable environmental characteristics of sites. The distance should be measured carefully site by site.
- · Take into account the following characteristics of radio waves.
 - **Body effect:** The RSSI value may differ depending on the location of the handset on the human body.
 - **Speed of moving handset:** The RSSI value may fluctuate if a handset moves at speed.
 - Line of sight: Much more consideration is required when a DBS is to be installed in a wide-open area.
 - **Multi-storey deployment:** Characteristics of cells in each storey may differ due to the structure and materials of the building.

Before Starting the Site Survey

Information Required

- Obtain a map of the site.
- Note the general construction materials used in walls and doors of the building(s), including window coating and covering, if any. Also note any large metal objects such as equipment, doors, and fluorescent lamp shades. In general, radio frequency (RF) signals are attenuated to some degree when passing though materials. Some materials, such as metal, attenuate RF signals to a higher degree. (See Table 2, above.)
- Define the number of handset users and which are the high traffic areas, such as conference rooms, cafeterias, and manufacturing departments.
- Check which positions allow and prohibit DBS installation.
- Determine the required coverage areas, such as elevators, stairwells, toilets, outdoor areas etc.
- Establish the position of the DECT system and available cabling.

Coverage Estimation

The available "link budget" of the Samsung DCS system is 40dB. The DCS system guarantees good communication quality and allows the user to move around if the "path loss" and "insertion loss" are less than the "link budget".

- Insertion loss: Signal attenuation caused by obstacles. (See Table 2, above.)
- Path loss: Signal attenuation caused by free air. (See table in Appendix A.)

Coverage estimation is done as follows:

- 1. Using the site map, select a reasonable DBS location.
- 2. Move away from this location and estimate the distance.
- 3. If there are any obstacles, determine the "insertion loss (dB)" of the obstacle(s) from Table 2, above.
- 4. From the table in Appendix A, read the "path loss" (RSSI value) corresponding to the estimated distance.
- 5. Repeat the procedure if you have any doubts about the location.



If the estimated distance is greater than 150m, communication may be possible but there is no guarantee of good quality or of a call being made.

Tools Needed for Site Survey

- Key telephone system: BSI card and DLI card with one DGP (digital keyphone)
- DBS: 1
- Handsets (Office DECT 8000): 1
- UTP cable (5m patch lead): BSI to DBS

- Tripod to hold DBS
- Power cable for AC feeding
- Tape measure
- Map of the building

Preparation of Site Survey (Cell Planning)

Configure the following test environment.



To carry out the site survey, you will need to:

- 1. Install the BSI card in the DCS or Compact II keyphone system.
- 2. Connect the DBS and the BSI card using the UTP cable.
- 3. Connect the power cord to the keyphone system.
- 4. Set the DECT system parameters.
- 5. Register selected Office DECT 8000 handsets to the DBS.

Refer to Chapter 4, Installation, for full details of all these procedures.

Site Survey Procedure

Before you start cell planning, the coverage estimation for the site should be completed and the possible DBS locations indicated on the site map. Cell planning is done as follows:

- 1. At a selected DBS location, set up the test configuration as shown in *Preparation of Site Survey* above.
- 2. Adjust the tripod to place the DBS near the ceiling or at a height of about 2.5m.
- 3. Press the ▼ button on the handset until you hear a short beep (after about three seconds) and then press button "2" within one second of hearing the beep.
- 4. The handset displays the RSSI value of the DBS (see Figure B-1, handset LCD display [8], shown in Appendix B).

- 5. Move away from the DBS and check the RSSI value until it reads **A0**. Stop and mark this as the border of the cell on the map. Note that:
 - When measuring RSSI values, hold the handset away from your body, pause for 2–3 seconds, take a reading and move on.
 - To avoid confusion, different cell boundaries should be marked with different line patterns, e.g. dashed line, dotted line, etc. Do not use colours as these may be lost when photocopying.
 - For a multi-storey building it must be clear on what floor the DBS was positioned and that the result may be several cell contours on different floors.
- 6. Using the following numbering conventions, name the DBSs and cells and mark them on the map.
 - xRyy :refers to the identity of the DBS, where
 - \boldsymbol{x} is the level (-1 is basement, 0 is ground, 1 is the 1st floor, etc) \boldsymbol{R} means this is a DBS
 - yy is the DBS position number. This number should be unique.

For example, a DBS on the 2nd floor and with position number 4 is identified as 2R04.

xCyy :refers to the identity of the cell, where
 x is the level at which the measurement was made (-1 is basement, 0 is ground, 1 is
 the 1st floor, etc)
 C means this is a cell
 yy is the position number of the DBS being measured.

For example, if measurement is made on the 2nd floor and the measured base station position number is 4, the identity of the cell is 2C04.

- 7. Repeat steps 1–6 for the remaining planned DBS positions. Cells should be at least adjacent to each other. Overlap is not required except where traffic density demands this.
- 8. At this stage, it may be necessary to move some of the planned DBS positions or add new ones to eliminate shadows or optimise cell size. If so, it may also be necessary to do additional measurements to check that the new DBS positions do not create other problems.

Choose the DBS positions required. This may need to be done in consultation with a customer engineer. In choosing DBS positions, the required cabling to the keyphone system should be considered. DBS positions must be defined such that later installation problems are minimised.

9. Having completed the above procedures, install the DBSs in the positions marked on the map.

Some example cell planning results are shown at the end of this chapter.

Checklist for Survey Data

Building Characteristics (list for each building)

- Building identification (refer to maps if available)
- What it is used for
- Dimensions (refer to maps if available)
- Number of floors
- Height of each floor
- Partitioning per floor
- Construction details

Radio Coverage

List areas where radio coverage is not necessary or which are to be excluded from radio coverage. Also list areas where radio coverage is not feasible or requires specific DBSs.

Keyphone System

Type and location of keyphone system (e.g. Compact II).

Connection Between BSI and DBS

For each DBS the following details of its connection to a BSI are required:

- Length of cable between BSI and DBS.
- Whether existing cabling might be used, and if so the type of cabling (e.g. twisted pair, star quad, wire diameter), presence of free pairs, etc.
- Cabling layout (risers, horizontal wiring, distribution frames).

Reporting Site Survey Results

It is important to make a comprehensive survey report that records site survey results and provides useful information for the engineer who is to actually install the equipment. The following information should be included in the survey report. (See the DECT Survey Report Form over the page.)

- A description of the site, explaining which buildings and grounds are to be included in the report. A description of the topography of outdoor areas may be useful.
- A specification of the construction of the buildings and construction materials.
- Customer requirements for:
 - the number of handsets
 - required coverage
 - performance requirements (traffic density, grade of service etc.)
- The location and the type of the keyphone system (DCS or Compact II).
- Cabling details: a specification of cables already present on the site and a list of new cabling required, including the distance between the DBS and BSI card for existing and new cabling.
- Copies of the maps of the site with the position of DBSs and cell boundaries clearly marked.
- A list of possible configurations to help the customer decide exactly what is required.
- A specification of where DBSs should be placed. This can be marked on the survey map, but additional information such as height and fixing instructions should be included where appropriate.
- A specification of the areas that will be covered by the DBS and areas that may cause problems. This can be useful when testing the system. The theoretical maximum number of overlapping cells is 10, if all time slots and frequencies are used. If not all time slots and frequencies are used, this value is higher, although this is unlikely to be the case in practical situations. For a large site where a thorough survey has been impossible, it may be prudent to add 10–20% more DBSs to requirements to allow for unforeseen problems.

DECT Survey Report Form

Number: Date:
From : [Survey Engineer] To : [Customer Installation Engineer]
1. SITE [full address of site]
2. Survey Engineers [name and addresses of engineer(s) who executed the survey]
3. Outline description of site [short description of site (dimensions, environment, number and type of buildings, etc)]
4. Number of handsets and expected traffic [description of expected traffic and indication of above- or below-average traffic areas]
5. Test results [this should include the site maps and any additional information that may be useful]
6. Connections–BSI to DBSs [list of planned DBSs with approximate cable length and type, and whether existing wiring can be used or new cabling is required]
7. Type and location of keyphone system [description, location and system configuration]
8. Existing cabling [indicate what cabling is available and how it is distributed across the site]
9. Base station installation [for each DBS, indicate exactly where it can be installed, e.g. "in the corridor against the wall of room 32, 2.5m high" and where customer restrictions apply as to where DBSs may be installed]
10. Possible configurations [list alternative configurations for the deployment of DBSs—refer to coverage maps and indicate areas where coverage cannot be guaranteed]

Example Cell Planning Results

Survey Map of the 1st Floor



Survey Map of the 2nd Floor



Survey Map of the 3rd Floor



Chapter 4 Installation

Installation Procedure

In this chapter you are taken through the following procedures:

- 1. Installing the BSI card in the keyphone system.
- 2. Connecting the BSI card to the DBS.
- 3. Installing the DBS.
- 4. Registering the DECT handsets with the DBS(s).

In practise, the normal sequence of activity would be to install the BSI card, connect to a DBS, register some handsets and carry out the site survey to establish the optimum DBS locations (as described in Chapter 3). The DBS(s) would then be installed in the locations determined in the site survey and all remaining handsets registered.

Before beginning installation, ensure the mains power is disconnected.

Installing the BSI Card

Installing 3BSI Card in Compact II

- 1. Check that there is no damage to the card.
- 2. Using a flat-bladed screwdriver, remove the two screws securing the front cover of the Compact II system and remove the cover.
- 3. You will see three empty slots (each with a long and a short connector—see illustration, below). Select one of these empty slots to install the card.



4. Insert the card into the selected slot.





Installing 4BSI and 8BSI Cards in DCS

ISDN cards such as a PRI or BRI card use the external clock from the public network. Therefore, when a Samsung DECT system uses PRI or BRI, the system must synchronize with the external clock as a slave. A BSI card also uses the same clock as ISDN cards. The Samsung DECT system determines the clock priority according to the card type and the slot position. The BSI card has the lowest clock priority, the PRI card the highest. The PRI card must be inserted in Slot 1 (the leftmost slot) with a vacant Slot 2. The BRI card must be inserted in a slot to the right of the PRI card, and the BSI card in a slot to the right of the BRI card. Other cards which do not use the external clock can be inserted in any remaining slots.

BSI cards can only be installed in the basic KSU of the DCS system.

Installing 4BSI Card in DCS

- 1. Check that there is no damage to the card.
- 2. Using a flat-bladed screwdriver, remove the two screws securing the front cover of the DCS system and remove the cover.
- 3. You will see nine slots. Since the leftmost and rightmost slots should have a PSU and ROM2 card installed, respectively, you can install the 4BSI card in one of the six slots Slot 1 to Slot 6 (but not Slot 7). Take note of the card priorities, above.

4. Place the card in the selected slot and pull out the two ejectors on the card front panel as shown in the diagram below.



5. Push the card into the slot until the ejectors are positioned at the slot entrance. Push down the ejectors to fix the card firmly on the backplane board.



Installing 8BSI Card in DCS

The 8BSI card can only be inserted in an odd-numbered slot (Slot 1, 3, or 5) and the next slot must be left empty.

Insert the card into the DCS system as follows.

- 1. Check that there is no damage to the card.
- 2. Using a flat-bladed screwdriver, remove the two screws securing the front cover of the DCS system and remove the cover.
- 3. You will see nine slots. Since the leftmost and rightmost slots should have a PSU and ROM2 card installed, respectively, you can install the 8BSI card into one of three slots (SLOT1, 3, or 5) in between.
- 4. Place the card in the selected slot and pull out the two ejectors on the front panel of the card as shown in the diagram below.



5. Push the card into the slot until the ejectors are positioned at the slot entrance. Push down the ejectors to fix the card firmly on the backplane board.



Connecting BSI Card and DBS

Cable Requirements

The DECT system performs best when both pairs of the twisted-pair cables have the same characteristics. The system supplies voltage to the DBS using the 'phantom feeding' method. Even if one line of a pair is broken, the voltage feed is maintained. If using existing wiring, check the diameter and length of cable carefully.

Characteristic	Requirements
Diameter	0.6mm or 0.4mm
Max length	 600m with 0.6 diameter 400m with 0.4 diameter
Interface	2xU interface & 64kbps via 4 B-channels

The cable connecting the BSI card with the DBS is a twisted-pair cable. One end is an RJ-45 connector (which connects to the DBS) and the other end is a champ connector (which connects to the BSI card), as shown in the diagram below.



The pin configuration of the champ connector depends on the type of BSI card. The following shows the pin configuration for the RJ-45 connector and champ connector for each system.

3BSI (installed in Compact II system)

Slot	RJ-45 Connector Pin No	Port	Signal	Champ Connector Pin No	Colour
	4		D channel data	50	S Pu
	5	0	D channel data	25	
	6	U	Sync line	49	Pp Du
	3			24	DIIFU
	4		D channel data	48	Cro Du
1	5	1		23	GII Pu
1	6	1	Como a litra a	47	O D
	3		Sync line	22	0 Pu
	4		Dalara al data	46	D D
	5		D channel data	21	B Pu
	6	Z	c ŀ	45	C Y
	3		Sync line	20	SY
	4			42	0 N
	5		D channel data	17	ΟY
	6	0	c li	41	N N
	3		Sync line	16	ВҮ
	4		D channel data 1 Sync line	40	S Bk
0	5	4		15	
Z	6	1		39	Bn Bk
	3			14	
	4		Daharan dalata	38	C Dl-
	5	_	D channel data	13	Gn Bk
	6	z	c l	37	
	3		Sync line	12	O BK
	4		, וו ות	34	
	5	D c	D channel data	9	Bn R
	6	0	c li	33	
	3		Sync line	8	Gn R
	4		5111	32	0 D
0	5	1	D channel data	7	O R
3	6		с ^у	31	
	3		Sync line	6	ВК
	4		. ייי ו ת	30	C W
	5		D channel data	5	SW
	6	" Z	2 Sync line	29	D TT
	3			4	Bn W

4BSI (installed in DCS system)

RJ-45 Connector Pin No	Port	Signal	Champ Connector Pin No	Colour
4	0	D channel data	1	B W
5			26	W B
6		Sync line	27	W O
3			2	O W
4	1	D channel data	4	Bn W
5			29	W Bn
6		Sync line	30	W S
3			5	S W
4	2	D channel data	7	O R
5			32	R O
6		Sync line	33	R Gn
3			8	Gn R
4	3	D channel data	10	S R
5			35	R S
6		Sync line	36	Bk B
3			11	B Bk

8BSI (installed in DCS system)

RJ45 Connector Pin No	Port	Signal	Champ Connector Pin No	Colour
4	0	D channel data	1	B W
5			26	W B
6		Sync line	27	W O
3			2	O W
4	1	D channel data	4	Bn W
5			29	W Bn
6		Sync line	30	W S
3			5	S W
4	2	D channel data	7	O R
5			32	R O
6		Sync line	33	R Gn
3			8	Gn R
4	3	D channel data	10	S R
5			35	R S
6		Sync line	36	Bk B
3			11	B Bk
4	4	D channel data	13	Gn Bk
5			38	Bk Gn
6		Sync line	39	Bk Bn
3			14	Bn Bk
4	5	D channel data	16	ВY
5			41	ΥB
6		Sync line	42	ΥO
3			17	O Y
4	6	D channel data	19	Bn Y
5			44	Y Bn
6		Sync line	45	Y S
3			20	S Y
4	7	D channel data	22	O Pu
5			47	Pu O
6		Sync line	48	Pu Gn
3			23	Gn Pu

Connecting Cable to Compact II

Connect the champ connector of the twisted-pair cable to the P2 connector of the Compact II basic cabinet or the P5 connector of the expansion cabinet as shown in the diagrams below.

3BSI – Compact II basic cabinet


Connecting Cable to DCS

Connect the champ connector of the twisted pair cable to the champ connector on the front panel of the 4BSI or 8BSI card.



Connecting Cable to DBS

This should be done before you install the DBS on its wall-mount bracket.

1. Connect the RJ-45 connector of the twisted pair cable to the LINK port on the rear of the DBS.



2. Push the cable into the groove below the LINK port so that the connector cannot be easily disconnected accidentally.



3. Attach a magnetic (ferrite) core to the cable at the location shown in the diagram below. Open the core, insert the cable, and close the core firmly. This provides electrical "noise" suppression for the DBS.



You now have a suitable system configuration to carry out a site survey to determine suitable locations for the DBS(s) as described in Chapter 3. It simply remains to connect the power cord to the DCS or Compact II main unit and switch the power on, set the DECT system parameters and register an appropriate number of handsets for testing (see *Setting DECT System Parameters* and *Registering Handsets* at the end of this chapter).

The next section describes how to install the DBS(s) in the required locations once testing is complete.

Installing the DBS

DBS installation is carried out only after the site survey has been completed to identify suitable locations (see Chapter 3). Switch off power to the DECT system and remove the power cord if necessary before starting installation.

Tools Required

You need the following items in order to install a DBS.

- DBS unit
- Wall-mount bracket
- Power drill
- Hammer
- Cross-head screwdriver
- Rawl plugs (2)
- Screws (2)
- If you are mounting the DBS on a wall made of a hard material such as marble or steel, you will need a wooden board larger than the wall-mount bracket.



Fixing the Wall-Mount Bracket

The method for fixing the wall-mount bracket differs depending on the wall material. The first method described is for mounting the bracket on a concrete wall. The second is for mounting on walls made of harder materials, such as marble or steel, which require a wooden mounting board.

Mounting on a Concrete Wall

1. Place the wall-mount bracket against the wall and mark two screw hole positions with a pen or pencil.



2. Use a power drill to drill holes on the marks you just have made. The holes should be at least 35mm deep with a diameter of about 5.5mm so that you can insert the rawl plugs easily.



3. Hammer the rawl plugs into the drilled holes.



4. Align the wall-mount bracket on the screw holes and screw into position with a cross-head screwdriver. Check that the wall-mount bracket is tightly secured to the wall.



Mounting on a Marble or Steel Wall

- 1. Prepare a wooden board on which you can fix the wall-mount bracket. The board should be larger than the bracket. Glue the board securely to the wall.
- 2. Place the wall-mount bracket against the board and screw into position with the cross-head screwdriver. Ensure both the wall-mount bracket and board are tightly secured to the wall.



Fixing a DBS on the Wall-Mount Bracket

Before you fix the DBS to the wall-mount bracket, be sure that you have already connected the RJ-45 cable to the rear of the DBS. This is described in the previous section, *Connecting BSI Card and DBS*.

There are two grooves on the back of the DBS unit that fix to the bracket. These are circled in the diagram below.



The grooves align with the two fixing tabs on the wall-mount bracket.



Align the grooves of the DBS with the bracket tabs and gently pull down the DBS to engage the tabs. Ensure the DBS is securely fixed to the bracket.



Connect the power cord to the DCS or Compact II main unit and switch on the power. When the DECT system is operating normally—and before any system programming is carried out—the LEDs on the DBS should display as follows:

Left LED: On steady Centre LED: On steady Right LED: Off

If your system is not operating correctly, refer to the *Troubleshooting* section in Chapter 6.

You must also ensure that your DECT system parameters are set up correctly and that you change the identification codes from the default values supplied. You can then register all your handsets. The following sections explain what you need to do.

Setting DECT System Parameters

Your Samsung DECT system must be identified to differentiate it from other DECT systems and to allow you to register handsets. Your system has two types of identifiers: the System ID and the Auth Code. The default values for these identifiers must be changed when you install the system or the system will not work. The values are changed in MMC 737, 'DECT System Code' (refer to Chapter 5, *MMC Programming*).

There is also a Registration On/Off option (see MMC 744, 'DECT Registration On/Off) to allow you to register handsets—and to prevent unauthorised users from registering handsets on the system.

System ID

The System ID (or PARI, Primary Access Rights Identity) comprises three hexadecimal digits (011– FFF; default 000) to distinguish between Samsung DECT systems. Each system has a unique System ID. Your dealer or system installer must program this unique System ID (using MMC 737) when the system is installed.

Authentication (Auth) Code

The Auth Code is used to verify a legitimate user of the DECT system. The code is four hexadecimal digits (0000–9999; default FFFF).



It should take no more than 10 minutes for the DBS to start operating normally after programming system parameters in MMC 737.

Registration On/Off

The Registration On/Off option (MMC 744) enables or disables DECT handset registration on a Samsung DECT system. It is disabled—turned off—by default. To enable registration you must enter a passcode when you run this MMC. If you want to change the default passcode, use MMC 202 (Change Feature Passcodes).

Remember—before you can register handsets on your DECT system, you must change the default values for the System ID and Auth Code, and the registration mode must be enabled.

Also, to prevent unauthorised users registering with your system, don't forget to disable registration mode when you've finished registering your handsets.

Registering Handsets

Office DECT 8000 Registration

Each handset must be registered to a DBS before it can be used. You can register each handset with up to four different DBSs.



Read Setting DECT System Parameters, above, carefully before reading this section.

You register each handset as follows.

- 1. Press the **MENU** button to display main menu items.
- 2. Press the ▼ or ▲ button repeatedly to select **5:System**, then press the **OK** button.
- 3. Enter the PIN code, then press the **OK** button.



```
Office DECT 8000 Handset
```



The PIN code is preset to "0000." For instructions on how to change this, refer to "Changing PIN" on page 40 of the Samsung Office DECT 8000 User's Manual.

- 4. Press the ▼ button to select 2:Register, then press the OK button.
- 5. Press the \checkmark or \blacktriangle button repeatedly to select the base number specified for the DBS.



If the check symbol (\checkmark) appears to the right of the base number, this indicates that the number is already registered on your handset.

- 6. Press the **OK** button. You will see the ID of the DBS.
- 7. Press the **OK** button. You will see the "Enter AC" message.
- 8. Enter the authentication code (AC) for the DBS (as set in MMC 737—see *Setting DECT System Parameters*, above.)
- 9. Press the **OK** button. You will see the "Please Wait" message. If registration has been completed successfully, the LCD window displays the handset number and the default handset name "SAMSUNG".

If you have any problems with registering handsets, or you cannot make a call from a handset, refer to *Troubleshooting* in Chapter 6.

Chapter 5 MMC Programming

MMC 202 : Change Feature Passcodes

Description

Used to change the passcode for DECT handset registration (in MMC 744).



The passcode is four digits long. Each digit can be 0-9. The current (old) passcode is required for this MMC.

Program Keys

Volume Up/Down	scroll through options	
Keypad	enter selections	
Soft keys	cursor left and right	
SPEAKER	store data and advance to the next MMC	

Action/Display

- 1. Press TRSF 202 Display shows
- Press Up or Down key to select DECT REGST and press the RIGHT soft key to move cursor to passcode entry
- 3. Enter new passcode via keypad (e.g. 6543)
- Press TRSF to store and exit OR Press SPEAKER to store and advance to next MMC

Default Data

DECT REGISTRATION PASSCODE : 4321

Related MMC

MMC 744: DECT REGISTRATION ON/OFF

CHANGE PASSCODE <u>D</u>AY/NIGHT :0000

CHANGE PASSCODE DECT REGST :4321

CHANGE PASSCODE DECT REGST :6543

MMC 724 : Dial Number Plan

Description

Used to change the phone number of a DECT handset.

Program Keys

Volume Up/Down	scroll through options	
Keypad	enter selections	
Soft keys	cursor left and right	
SPEAKER	store data and advance to the next MMC	
HOLD	clear previous entry	

Action/Display

- 1. Press TRSF 724 Display shows
- 2. Press Up or Down key to select DECT STN DIAL NO and press RIGHT soft key
- 3. Press Up or Down key to select DECT01/02/03 etc and press RIGHT soft key to advance cursor
- 4. Enter new number via keypad (e.g. 4001)

If the entered number is already used by a handset, you see the following message

Enter 1 to accept the change, or 0 for no change

- 5. The new phone number is displayed
- Press TRSF to store and exit OR Press SPEAKER to store and advance to next MMC

Default Data

DECT STN DIAL NO : 7901—7948 (DCS) DECT STN DIAL NO : 7901—7924 (Compact II) <u>S</u>TN DIAL NUM :C1 S5-PO7::204 →

DECT STN DIAL NO DECT01:7901→

DECT STN DIAL NO DECT01:7901→

DECT STN DIAL NO DECT01:7901→4001

SAME DIAL EXIST CHANGE? Y:1, N:0

DECT STN DIAL NO DECT01:4001 \rightarrow

MMC 737: DECT System Code

Description

Used to identify your DECT system and the handsets you register with your system.

The DECT System Code for your system is made up of two fields: the System ID which is three hexadecimal digits in the range 011 to 999; and the Auth Code (short for Authentication Code) which is four hexadecimal digits in the range 0000 to 9999. The default values are 000 and FFFF respectively.

Important You must use this MMC to change the default values for the values you have been provided with by your supplier. If you do not change the defaults you will not be able to register handsets.

Once you have entered your new System ID and Auth Code using this MMC you can then begin registering your handsets with the Auth Code. The system checks the Auth Code entered for each handset against the DECT Auth Code. If it is the same, the registration procedure continues; otherwise, the DCS rejects the registration procedure.

<u>Caution:</u> Only the system administrator and/or installer should be allowed access to change the DECT System Code and register handsets.

Program Keys

Volume Up/Down	scroll through options	
Keypad	enter selections	
Soft keys	cursor left and right	
SPEAKER	store data and advance to the next MMC	
HOLD	clear previous entry	

Action/Display

- 1. Press TRSF 737 Display shows
- 2. Press RIGHT soft key to move cursor and enter AUTH CODE via keypad (e.g. 1234)
- 3. Press RIGHT soft key and press Up or Down key to select SYSTEM ID
- 4. Press RIGHT soft key to move cursor and enter SYSTEM ID via keypad (e.g. 567)
- Press TRSF to store and exit OR
 Press SPEAKER to store and advance to next MMC

Default Data

SYSTEM ID: 000 AUTH CODE: FFFF

Related MMC

MMC 738: CLEAR REGISTRATION

DECT SYSTEM CODE <u>A</u>UTH CODE : FFFF

DECT SYSTEM CODE AUTH CODE : 123<u>4</u>

DECT SYSTEM CODE SYSTEM ID : 000

DECT SYSTEM CODE SYSTEM ID : 56<u>7</u>

MMC 738 : Clear Registration

Description

Used for deleting previously registered information for DECT handsets.

This MMC has two modes:

• FORCED mode

In the forced mode, the system clears the registered information by force.

• NORMAL mode

In the normal mode, the system will delete the registration information for a DECT handset after confirming from the handset. If the confirmation is successful, the system clears the registered information. (If the confirmation fails, the system cannot clear the information.)

Program Keys

Volume Up/Down	scroll through options	
Keypad	enter selections	
Soft keys	cursor left and right	
SPEAKER	store data and advance to the next MMC	
HOLD	clear previous entry	

Action/Display

- 1. Press TRSF 738 Display shows
- 2. Enter number of DECT handset to clear via keypad and press the RIGHT soft key to move the cursor
- 3. Select the de-registration (clear) mode via Up or Down key (e.g. Normal) and press the RIGHT soft key to move the cursor
- Enter 1 for Yes or 0 for No OR Press Up or Down key to select Yes or No
- Press TRSF to store and exit OR Press SPEAKER to store and advance to next MMC

Default Data

MODE : FORCED

[<u>7</u>901]DECT CLEAR MODE: FORCED

[<u>7</u>901]DECT CLEAR MODE: FORCED

[7901]DECT CLEAR MODE: <u>N</u>ORMAL

[7901]DECT CLEAR	
DECT CLEAR:YES	

MMC 739 : BSI Download

Description

Used to download a new version of the DBS software when you upgrade to a new version of BSI ROM.

Program keys

Volume Up/Down	scroll through options	
Keypad	enter selections	
Soft keys	cursor left and right	
SPEAKER	store data and advance to the next MMC	
HOLD	clear previous entry	

Action/Display

- 1. Press TRSF 739 Display shows
- 2. Select the slot number via UP or DOWN key, e.g. 3
- 3. Select the DBS number via UP or DOWN key, e.g. 1
- 4. Press Up or Down key to select Yes for download and then confirm download

When downloading is in progress, the display shows

However, if a downloading failure occurs, the display shows

 Press TRSF button to store and exit OR Press SPK button to store and advance to next MMC

BSI SLOT:2 DBS:1
DOWNLOAD? NO
BSI SLOT: <u>3</u> DBS:1
DOWNLOAD? NO
BSI SLOT:3 DBS: <u>1</u>
DOWNLOAD? NO
BSI SLOT:3 DBS:1
DOWNLOAD? <u>Y</u> ES
BSI SLOT:3 DBS:1
ARE YOU SURE? <u>Y</u> ES
BSI SLOT:3 DBS:1
DOWNLOADING
BSI SLOT:3 DBS:1
DOWNLOAD FAIL

MMC 740 : Station Pair

Description

Allows a DECT station to be assigned as a 'secondary' to a 'primary' DGP station (keyphone) in the system. This will allow all features to be set or cancelled from either station, and both will ring when the 'primary' receives a call.

Program keys

Volume Up/Down	scroll through options	
Keypad	enter selections	
Soft keys	cursor left and right	
SPEAKER	store data and advance to the next MMC	
HOLD	clear previous entry	

Action/Display

- 1. Press TRSF 740 Display shows
- Enter the primary station number via keypad (e.g. 201) OR

Press Up or Down to select number and press RIGHT soft key

 Enter the secondary station number via keypad (e.g. 205) OR
 Press Up or Down key to select number and press

Press Up or Down key to select number and press RIGHT soft key

 Press TRSF to store and exit OR Press SPEAKER to store and advance to next MMC

[201] PRIMARY
SECONDARY:NONE

[201] PRIMARY SECONDARY:NONE

[201] PRIMARY	
SECONDARY:205	

MMC 741 : DBS Restart

Description

Used to restart a BSI card or DBS. When you use this MMC, the DBS/BSI will be restarted automatically.

Program keys

Volume Up/Down	scroll through options	
Keypad	enter selections	
Soft keys	cursor left and right	
SPEAKER	store data and advance to the next MMC	
HOLD	clear previous entry	
ANS/RLS	select All	

Action/Display

- 1. Press TRSF 741
- 2. Select the specific BSI slot number or press the RIGHT soft key and select the specific DBS (using the keypad or the Up/Down keys)

(If you want to restart **all** DBSs, you must select "A" instead of a DBS number by pressing the ANS/RLS key)

Press the RIGHT soft key

- 3. Press Up or Down key to select Yes or No and press RIGHT soft key
- 4. Confirm whether you want to restart by selecting YES or NO using the Up or Down key, and press RIGHT soft key
- Press TRSF to exit OR Press SPEAKER to advance to the next MMC

BSI SLOT : 2	DBS : 1
RESTART ?	NO

BSI SLOT : <u>2</u>	DBS : 1
RESTART ?	NO

ſ	BSI SLOT : 2	DBS : 1
	RESTART ?	<u>Y</u> ES

BSI SLOT : 2 DBS	: 1
ARE YOU SURE ?	<u>Y</u> ES

MMC 742 : BSI Status

Description

Shows the status of the BSI card.

Action/Display

1. Press TRSF 742

Display shows:

For **Compact II**—"SUCC" (successful) if status of BSI card is normal, or "FAIL" if not

Or

For **DCS** — "M" = Master, "S" = Slave (not used): "SUCC" (successful) if status of BSI card is normal, or "FAIL" if not

 Press TRSF to store and exit OR Press SPEAKER to store and advance to next MMC

BSI STATUS	
SUCC	

Or

BSI STATUS M:SUCC S:NONE

MMC 743 : DBS Status

Description

Used for checking the status of the DECT base stations (DBS).

Action/Display

- 1. Press TRSF 743
- 2. The status of each DBS is displayed: If status is normal, "1" is displayed If status is not normal, "0" is displayed

For **DCS**—(DBS=1–8) (e.g. 1, 2, 3, 5 and 6 are normal)

Or

For **Compact II**—(DBS=1–3) (e.g. 1 and 2 are normal)

 Press TRSF to store and exit OR
 Press SPEAKER to store and advance to next MMC

DBS :12345678	
STS : 11101100	

DBS	STA	TUS	
1:1	2:1	3:0	

MMC 744 : DECT Registration On/Off

Description

Enables DECT handset registration on a DECT system. If this MMC is not executed and an attempt is made to register a DECT handset, an error message will be displayed. A passcode is required to enable registration. The default passcode can be changed using MMC 202 (*Change Feature Passcodes*).

Caution: When you have finished handset registration, run this MMC again and reset it to DISABLE to prevent unauthorised registration.

Program keys

Volume Up/Down	scroll through options
Keypad	enter selections
Soft keys	cursor left and right
SPEAKER	store data and advance to the next MMC
HOLD	clear previous entry

Action/Display

- 1. Press TRSF 744 Display shows
- 2. Enter passcode

If the correct code is entered the display shows

An incorrect code entry shows

If the System ID in MMC 737 (*DECT System Code*) has not been set, the message shown will be displayed

- Dial 1 for ENABLE or 0 for DISABLE OR Press Up or Down key to select and press RIGHT soft key
- Press TRSF to exit OR Press SPEAKER to store and advance to next MMC

Default Data

DISABLE Related MMC

MMC 202 : CHANGE FEATURE PASSCODES

ENABLE DECT REG. PASSCODE:

ENABLE DECT REG. PASSCODE:********

ENABLE DECT REG. DISABLE

ENABLE DECT REG. PASSCODE ERROR

ENABLE DECT REG. NO REG. SYSTEM ID

ENABLE DECT REG. ENABLE

MMC 745 : BSI Carrier

Description

A base station uses one of 10 channels (FDMA technology). This MMC is used to allow or deny the use of each channel (carrier). By default, all carriers can be used by a base station.

Program Keys

Volume Up/Down	scroll through options
Keypad	enter selections
Soft keys	cursor left and right
SPEAKER	store data and advance to the next MMC
HOLD	clear previous entry

Action/Display

1. Press TRSF 745

The display shows the status of each carrier (0 - 9):

If '1' is shown below a carrier then this carrier can be used by the base station

If '0' is shown below a carrier then this carrier cannot be used by the base station

- 2. Dial 1 or 0 for each carrier (e.g. 0 for carriers 0 and 1)
- Press TRSF to store and exit OR Press SPEAKER to store and advance to next MMC

Default Data

11111111111

CARS:0123456789	
SELS: 1111111111	

CARS:0123456789	
SELS: 0011111111	

Chapter 6 Maintenance

Upgrading Software for BSI Card and DBS

Upgrading Software for BSI Card

3BSI card

Software for the 3BSI card is stored on a ROM chip on the card. Upgrading software simply involves replacing the existing ROM with a new version in the position shown below. Use a chip extraction tool to remove the old ROM, position the new ROM carefully over the vacated slot and push down gently but firmly to fix it in position.



4BSI Card

Software for the 4BSI card is stored on a ROM chip on the card. Upgrading software simply involves replacing the existing ROM with a new version.

1. Loosen the four screws on the cover of the 4BSI card, and remove the cover.



2. Use a chip extraction tool to remove the old ROM from the card (see below), position the new ROM carefully over the vacated slot and push down gently but firmly to fix it in position.



3. Replace the cover and screws.

8BSI Card

Upgrade software for the 8BSI card is downloaded to your system via a console terminal. The console terminal can be an ASCII terminal such as a VT-100 or VT-220, or a PC installed with a terminal emulation program (such as Windows HyperTerminal).

Connecting the Console Terminal

When you connect the 8BSI card to the console terminal, use a console cable with 9-pin RS-232C connectors as shown below.



Male	Female
2 —	 2
з —	- 3
5 —	- 5

Port configuration for the RS-232C cable

Connect one end of the console cable to the RS-232C connector of the 8BSI card and connect the other end to a serial port on the console terminal, as shown below.



Configuring the Console Terminal

The console terminal should be set up with the following parameters:

- Emulation: VT-100/ANSI Compatible
- Bps: 9600
- Stop bit: 1
- Data bit: 8
- Parity bit: None
- Flow control: None

On a PC, the software download procedure employs the HyperTerminal feature in Windows. This is described next.

Downloading Software Using Windows HyperTerminal

Setting Up HyperTerminal

- 1. Switch on the PC and boot with Windows95 or later.
- 2. Click [Start] at the bottom of the screen and select Program → Accessories (in Windows 95) or Program → Accessories → Communications (in later Windows versions). Select Hyper-Terminal from the displayed menu.
- 3. When you see the following HyperTerminal window, click the Hypertrm icon



4. When you see the following <Connection Description> window, type a name for the connection in the "Name" box (e.g. 8BSI) and select an icon from the icons displayed in the "Icon" box. Then, click [OK].

Connection Description
New Connection
Enter a name and choose an icon for the connection:
Name: BBSI
Joon 💑 🌏 🌭 🗠 🍪 🦻
OK Cancel

5. You see the following <Phone Number> window. The console terminal is connected to the 8BSI card through a COM port (e.g. COM2). Select the relevant COM port in the "Connect using" list and click [OK].

Phone Number	? ×
8 851	
Enter details for the	phone number that you want to dial:
Country code:	Y
Ar <u>e</u> a code:	
Phone number:	
Co <u>n</u> nect using: 🚺	irect to Com 2
	OK Cancel

6. You see the <COMx Properties> window for the COM port you selected (e.g. COM2). Configure the parameters for the COM port as shown and click [OK].

COM2 Properties	? ×
Part Settings	
Bits per second: 96	00 💌
Data bits: 8	×
Parity: No	ne 💌
Stop bits: 1	
Elow control: 🕅	ne 💌
Arture and	Restrice Data da
govarced	Terrore Denaute
OK.	Cancel (200)

7. The new HyperTerminal window appears.



Downloading the Software

8BSI card software is upgraded by downloading the files BSIROM.HEX and DBSROM.HEX from the console terminal. First, copy these two hex files into a directory on the console terminal. Then, download the files to the BSI card as follows.

1. The following message appears on the console if the 8BSI card is operating normally.

Press the Enter key.

2. Type **flo** at the <BSI> prompt and press the Enter key. The following menus appear.



3. Select menu [1] to download the BSIROM.HEX file from the terminal to the BSI card. The following message appears.

Selected 1) BSI HEX FILE Loading Please Start Loading!!

4. Click **Transfer → Send Text File...** menu from the HyperTerminal menu.

🎭 8BSI - HyperTerminal	
Eile Edit View Call	Iransfer Help
D 📽 🞯 🅉 💷	Send File <u>R</u> eceive File Capture Text
	Send Lext File
	Capture to Ennter

5. The <Send Text File> window appears. Select the BSIROM.HEX file and click [OK] to begin downloading.

Send Text File				? ×
Folder	🔄 download	٠	🗈 💈	1 🖻 🖻 🖻
Dbarom hex	e.			
Ele name:	Bairom hex			OK N
Eile type:	All files (".")		٠	Cancel

6. When downloading is complete, the following is displayed.



It will take about 15 minutes to finish downloading the file to the 8BSI card.

.....

.....

7. Press L and the following menus will be displayed again.

8. Select menu [2].

9. Repeat steps 4 and 5, but this time select DBSROM.HEX to begin downloading the file to the 8BSI card.

10.When downloading is complete, press **R**.

The following message will be displayed when the two hex files have been downloaded successfully.

Upgrading DBS Software

The software for the DBS is stored in the flash ROM mounted on the DBS. The BSI card software includes the DBS software, and when the card is started it will check the DBS software version. If it is an old version, it will be updated automatically with software from the BSI card.

The software from the BSI card is stored in RAM on the DBS during downloading. When downloading is complete, the software is copied to the flash ROM on the DBS.

Tools Required for Maintenance

The following tools are required to maintain your DECT system.

- Pair of long nose pliers
- Wire cutters
- Set of screwdrivers
- EPROM remover
- Anti-static wristband
- Multimeter

LED Descriptions

LEDs on the DBS

LED Location & Cadence		adence	Maaning				
Left	Centre	Right	weating				
OFF	OFF	OFF	DBS is not working.				
ON	OFF	OFF	5V Power ONRemote voltage feeding is good and DC-DC converter is working well.				
ON	Flash	OFF	DBS is initialising (TCM link, multi-sync setup).				
ON	ON/OFF	Flash	Normal operationON : at least one call is being servicedOFF : no call is being serviced.				
ON	ON	ON	RFP busyNo voice channel available4 channels are occupied.				
ON	Flash slowly	Flash slowly	DBS program is being downloaded from BSI.				
ON	Flash quickly	Flash quickly	DBS program being copied into the EEPROM after completion of download.				
ON	Flash	ON	During normal operationMulti-frame sync is outLED will be steady after re-sync.				
ON	OFF	Flash	CPU is working normally.				

Troubleshooting

Problem	Action	Remarks
Red LED on ROM card is not flashing	Check the power module and power connector.Check the MP program ROM on the ROM card and SP ROM on the main board.	
Left LED of DBS is OFF	 Check the power to the DBS and display DGP (keyphone) If DGP is powered, check line connection between the BSI and DBS. Check the SYSTEM ID via MMC 737 when using 8BSI. 	Use a multimeter
Right LED of DBS is not flashing	• Check the CPU circuit on the DBS and reset DBS using MMC 741.	
Centre LED of DBS is flashing continuously at initialisation	TCM link and multi-sync are not set upCheck the link status and RJ-45 connector.	
Cannot register handset	 Check registration mode is enabled Check System ID and AC changed from default value (MMC 737). 	
Cannot make a call	 Check right LED of DBS is flashing Check handset is registered correctly Check whether the number is the same as that of another handset. If so, select a handset and de-register it. 	
Cannot hand over	 Check the RF coverage area to the overlap cell for handover Check the direction or location of the DBS. Check the cable lengths between adjacent DBSs are less than 200m. 	

Refer to the following flow diagrams for more details.

Check Main System Power





If Right LED of DBS is Not Flashing





If Centre LED of DBS is Flashing Continuously at Initialisation

If Centre LED of DBS is Flashing During Operation



If DECT Handset Cannot Be Registered







Call Does Not Hand Over



Appendix A Open Site RSSI Level



Distance (m)	100	150	200	250	300	350	400
RSSI (dec)	200	191	182	180	171	162	150
RSSI (hex)	C8	BF	B6	B4	AB	A2	96

Appendix B Office DECT 8000 Handset Test Mode Descriptions

Running Test Mode

You can enter into the test mode while the handset is idle or while you are making a call. Press the \checkmark button until you hear a short beep (after about 3 seconds) and then press button "2" within one second of hearing the beep. (If the number is displayed, you have to start again by pressing the \checkmark button.) When in test mode, you see the following display. To exit from test mode, press the \checkmark button until you hear a short beep again.





(1) Locked RFPI value.

You will see an RFPI value, similar to "1001E56903". In this example, "1001E" is the Samsung ID, "569" is the SYSTEM ID value entered via MMC 737, and "03" is the installed DBS number.

- (2) Secondary base station number (RPN) to handover. Installed DBS number.
- (3) Frequency number of primary dummy for the secondary base station. (Range 0–9.) You will see this data only when the handset attempts to move into range of another DBS.
- (4) Slot number of primary dummy for the secondary base station. (Range 0–B.) You will see this data only when the handset attempts inter-cell handover.
- (5) RSSI value for the secondary base station. (Range 00–FF.)You will see this data only when the handset attempts inter-cell handover.
- (6) Frequency number of primary dummy for the first base station which is locked with the handset. (Range 0–9.)A DBS must send information for handsets to lock with the DBS via a beacon channel. This value is the frequency number for the beacon channel.
- (7) Slot number of primary dummy for the first DBS which is locked with the handset. (Range 0–B.)
- (8) RSSI value for the primary base station. (Range 00-FF.)
- (10) Slot number for a traffic channel.
 You will see this only when a traffic channel is established. (Range is 0–B.)
- (11) RSSI values for a traffic bearer.
 You will see this only when a traffic channel is established. (Range 00–FF.)
- (12) Number of attempts to establish a traffic channel for a call. This value has almost all zeros in the normal state, but this value may be increased depending on the cell environment. That is, if you try to set up a line at a bad cell (e.g. an out of service area or overlapping area among cells) you will see that the value is greater then zero.
- (13) Error rate for RX data. (Range 0-100.)
- (14) Error rate for TX data. (Range 0–100.)
- (15) Count for RX CRC. (Range 0-99.)
- (16) Count for TX CRC. (Range 0-99.)



If using a handset within the service area, the error rate is almost always zero in the steady state. However, if you change the position of the handset, these values are increased.

If data error occurs, the handset adds the current CRC count to the previous CRC count. If you want to clear these values, you have to press a number key. These values are set to "00".

- · Fast RSSI display mode: update by 0.6 seconds
 - If you pressed key "1" to enter running test mode.
- · Slow RSSI display mode: update by 2 seconds
 - If you pressed key "2" to enter running test mode.
 - Be able to see a normal display at a different time.

Handset Factory Reset

What is the purpose of this mode?

To erase all registered information, the Phonebook and Redial memory.

How do you enter this mode?

- Switch off the handset.
- **2** Switch on the handset while pressing keys "1" and "3" at the same time.

Samsung Telecoms (U.K.) Limited Brookside Business Park, Greengate, Middleton, Manchester M24 1GS Tel: 0161 655 1100 Fax: 0161 655 1166

